USA Assembly and Operating Instructions

Carrera®

RACING SYSTEM

NASCAR®

Stadlbauer Marketing + Vertrieb Ges.m.b.H.
Magazinstraße 4 · 5027 Salzburg · Austria
www.carrera-toys.com · www.carreraclub.com

62159













7.60.12.02.44

USA Subject to technical and design-related changes.

WARNING:
CHOKING HAZARD- Small parts.
Not for children under 3 years.

11/06 2006







USA

Please read this manual carefully and keep it for future reference.
Please check the contents of the package to make sure that it is complete and that no damage has occurred during transportation.

Safety Notices:
Not suitable for children under 3 years because of small parts or functional clamping danger.
The battery case is not a toy. Avoid short circuits by keeping the opposite poles away from each other.

Notice for parents:
Check the battery case periodically for damage. Only the recommended battery case should be used.
Never use more than one battery case. In case of damage do not attempt to continue to use the battery case. Do not open the speed controls. Remove the plug of the battery case from the connecting section when not in use.

Use a screwdriver to unscrew battery case. Remove the top of the case and place 4 batteries type „D" as indicated on the inside of the battery case.
When the batteries are inserted properly, replace the top and screw back in place with a screwdriver.

Check the track, vehicles, and parts periodically for damage.

Defective parts should be repaired or replaced.
The set has been designed for indoor use only.
Keep liquid substances away from all electrical connections.

Keep metal objects away from the track as they can cause short circuits. Vehicles travelling at high speed can fly off the track, therefore keep the track away from delicate objects to avoid damaging them.

It is not recommended to set the track up on carpet floors.
Always remove the plug of the battery case before cleaning or servicing the track. Never use cleaning agents or water.
For best results, store the track in the original packaging when not in use.
Always make sure that the contact brushes are in good working order.
Do not lock or hold the cars while the engine is on. This may lead to overheating and engine breakdown.
Driving too fast may cause the cars veering off the track.
This is not a misfunctioning of the cars but a reaction on driving at very high speed.

Do not operate racing-track in face or eye level.

During operation small car parts as spoilers or mirrors may get off or brake due to being original detailed parts of the car model. To avoid this it is possible to remove them before operation.

Technical Information:
This set requires 4 batteries type "D" (not included).
Do not mix old and new batteries!
Do not mix alkaline, standard (carbon-zinc) or rechargeable (nickel-cadmium) batteries.
Do remove batteries when not in use or discharged.
Do not dispose the batteries in fire! Batteries may leak or explode!

Please note that any parts of the battery operated Carrera Racing System set are not compatible with the Carrera GO!!! System!

AGE 4+

Conforms to the safety requiments of ASTM F963-03.